



NOTES:

1. Post Base To Fit 2" X 2" "Unistruct Telespar" 12 Ga. Or Equal Sign Post.
2. Secure To Concrete Using Four (4) 5/8"-11x4" Hot Dipped Galvanized Steel Hex Head Bolts And Zinc Finish Set-Bolt Anchors.
3. Trim The Corners Of The Bottom Plate To 1/4" Radius. Finish The Edges Of The Bottom Plate.
4. Construct Swing-Away Apron Per Drawing 2120 If Sign Post Restricts Pedestrian Walkway To Less Than 5' Width.



WASHINGTON COUNTY
DEPARTMENT OF LAND USE &
TRANSPORTATION
ENGINEERING SECTION

**SIGN POST INSTALLATION
SIDEWALK SURFACE MOUNT
SQUARE**

PLOT STAMP: 07/24/18 10:03A ANTHONYD
CAD: 6051.DWG

EFFECTIVE DATE: **8/01/2018**

WASH. CO. #

6051